9. PRESS START RESET AND THEN START KEY. THE PROGRAM WILL HANG-UP IN AN UNENDING LOOP. INDIVIDUAL METER WILL BE PARTIALLY CHECKED NOW FOR ENABLE OR DISABLE CONDITIONS

1402 — NON PROCESS RUN OUT THE PUNCH. 1402 METER STOPS. CPU METER CONTINUES RUNNING. PRESS 1402 CHECK RESET.

1403 — OPEN PRINTER GATE. 1403 METER CONTINUES RUNNING. CLOSE GATE AND PRESS SPACE KEY. PRINTER METER STOPS. CPU METER CONTINUES RUNNING.

1404 — NON PROCESS RUN OUT THE CARD FEED. 1404 METER STOPS. CPU METER CONTINUES RUNNING. PRESS 1404 CHECK RESET.

1011 — UNLOAD TAPE FROM READ HEAD. 1011 METER STOPS. CPU METER CONTINUES RUNNING.

1012 — PRESS THE TAPE FEED SWITCH. 1012 METER STOPS. CPU METER CONTINUES RUNNING.

1418 — ACTIVATE END OF TRANSPORT SWITCH. SORTER READER METER STOPS.
1428 CPU METER CONTINUES RUNNING.
1419
1412

729 — SET THE CONSOLE TAPE SELECT SWITCH TO -1-. ALL TAPE METERS
7330 STOP. CPU METER CONTINUES RUNNING. RETURN SWITCH TO -N-, ALL TAPE METERS RUN AGAIN. MANUALLY REWIND EACH SELECTED TAPE. EACH TAPE METER STOPS WHEN LOAD POINT IS REACHED. CPU METER CONTINUES RUNNING.

1009 — ASSIGNABLE UNITS.
1405 SET ALL ASIGNABLE UNIT METER SWITCHES OFF. CPU AND UNIT METERS
1407 CONTINUE RUNNING.
1311

PRESS CPU STOP KEY. ALL METERS STOP. PRESS CPU START. ONLY CPU METER RUNS.

SET ALL UNIT METER SWITCHES ON. ONLY CPU METER RUNS.

PRESS CPU STOP. SET ALL UNIT SWITCHES OFF EXCEPT 1311 SATELLITE DRIVES.

PRESS CPU START. ONLY CPU METER STARTS RUNNING.