1011 METER CHECK-OUT

THE FOLLOWING PROGRAM IS LOADED WITH THE MAIN PROGRAM.

```
1020 M ΣP1 657 R
1028 B *28
```

• 1. MAKE THE 1011 READY. START THE PROGRAM AT 1020. BOTH METERS SHOULD RUN. REMOVE TAPE FROM READ HEAD. ONLY CPU METER SHOULD RUN.

1012 METER CHECK-OUT

THE FOLLOWING PROGRAM IS LOADED WITH THE MAIN PROGRAM.

```
1040 M ΣP1 653 W
1048 B *48
```

• 1. MAKE THE 1012 READY. START THE PROGRAM AT 1040. BOTH METERS SHOULD RUN. PRESS TAPE-FEED-KEY. ONLY CPU METER SHOULD RUN.

1412 - 1419 METER CHECK-OUT

THE FOLLOWING PROGRAM IS LOADED WITH THE MAIN PROGRAM.

```
1060  U ΣS1 E
1065  U ΣS1 D
1070  B *70
```

1. MAKE THE 1412 OR 1419 READY — PUT DOCUMENTS IN HOPPER, ETC. START THE PROGRAM AT 1060. CPU AND 1412/19 METER SHOULD RUN.

2. MANUALLY ACTIVATE ANY JAM MICROSWITCH. ONLY CPU METER SHOULD RUN.

• 3. START THE PROGRAM AT 1060. MANUALLY ACTIVATE END-OF-TRANSPORT SWITCH. ONLY CPU METER SHOULD RUN.

4. REMOVE DOCUMENTS FROM THE HOPPER. START THE PROGRAM AT 1060. ONLY CPU METER SHOULD RUN.

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| DATE | 4/15/64 | | | | | | | |
| ENG. CHG NO | 120301 | | | | | | | |