1418 - 1428 METER CHECK-OUT

THE FOLLOWING PROGRAM IS LOADED WITH THE MAIN PROGRAM.

```
1040  U %S2 E
1045  U %S2 O
1050  B #50
```

1. MAKE THE 1418 OR 1428 READY -- PUT DOCUMENTS IN HOPPER, ETC. START THE PROGRAM AT 1040. CPU AND 1418/28 METER SHOULD RUN.

2. MANUALLY ACTIVATE ANY JAM MICROSWITCH. ONLY CPU METER SHOULD RUN.

3. START THE PROGRAM AT 1040. MANUALLY ACTIVATE END-OF-TRANSPORT SWITCH. ONLY CPU METER SHOULD RUN.

4. REMOVE DOCUMENTS FROM THE HOPPER. START THE PROGRAM AT 1040. ONLY CPU METER SHOULD RUN.