

### III. After D.T.'s are Running

After the desired D.T. has loaded and started to run, the Sense Switches must be set according to operation desired as indicated in each D.T. write-up.

## OPERATION

### I. Card to Tape Procedures

- A. Load "C.E.D.T. Card to Tape Program", Deck F 7100 into 1402.
- B. Place diagnostic decks in desired order behind the F 7100 deck.
- C. Load blank (not file protected) tape on Tape Drive Number 6.

Tape on Drive Number 6 will become Master Diagnostic Tape.

- D. Reset 1401 and press load key on 1402. Tape Drive Number 6 should be in ready status.

#### Notes:

1. Make sure the fourth card in each diagnostic deck contains the DFT ID#. The first three cards of each deck, (Diagnostic Clear Storage and Bookstraps Cards) MUST have CLR A, CLR B, CLR C in columns 76 to 80 respectively for Card to Tape Program to work.
2. Error and Informative Printouts will print on 1403.
3. After the last card of the last Diagnostic is run out, with Sense Switch "A" on, the Program will write the "End Routine" on tape, and will automatically write two (2) tape marks and rewind (on 729, the TD will also unload).

### II. Operating Procedures for Running D.T.'s Loaded on Tape

#### A. With 1407 Unit

1. Load Diagnostic Tape (File Protected) on Drive Number 1.
2. Clear and Reset machine.