


900 183 678
 907 458 676
 914 900

457 2nd (A FIELD - 271)
 673 000 340 (DIVIDEND - 340)
 918 010 (QUOTIENT - 012 REMAINDER - 016)



DATE	CHANGE NO.	DATE	CHANGE NO.	INTERNATIONAL BUSINESS MACHINES CORP		
4-10-62	113-10 D	31.7.62	TA 1370 K	NAME	FIGURE 52	% AAA 888
				DIVIDE		
				DESIGN		TYPE
				DETAIL		SCALE NONE
				CHECK		DRAW VE 326-62
				APPRO		CHECK

900 103 678 457 2P (A FIELD -27)
 907 458 676 673 000 345 DIVIDEND - 345
 914 900 918 010 QUOTIENT - 912 REMAINDER - 016

CYCLE	A		B		A AUX		B AUX		A		B		I	
	676	675	674	677	678	675	677	678	675	677	676	675	674	673
1	457	2	2	0	0	0	0	0	0	0	0	0	0	0
2	2	0	0	0	0	0	0	0	0	0	0	0	0	0
3	2	0	0	0	0	0	0	0	0	0	0	0	0	0
4	2	0	0	0	0	0	0	0	0	0	0	0	0	0
5	456	0	0	0	0	0	0	0	0	0	0	0	0	0
6	675	674	673	678	677	676	675	674	677	676	675	674	673	672
7	0	0	0	0	0	0	0	0	0	0	0	0	0	0
8	0	0	0	0	0	0	0	0	0	0	0	0	0	0
9	0	0	0	0	0	0	0	0	0	0	0	0	0	0
10	0	0	0	0	0	0	0	0	0	0	0	0	0	0
11	0	0	0	0	0	0	0	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0	0	0	0	0	0	0	0
13	0	0	0	0	0	0	0	0	0	0	0	0	0	0
14	0	0	0	0	0	0	0	0	0	0	0	0	0	0
15	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0
17	0	0	0	0	0	0	0	0	0	0	0	0	0	0
18	0	0	0	0	0	0	0	0	0	0	0	0	0	0
19	0	0	0	0	0	0	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0	0	0	0	0	0	0
21	0	0	0	0	0	0	0	0	0	0	0	0	0	0
22	0	0	0	0	0	0	0	0	0	0	0	0	0	0
23	0	0	0	0	0	0	0	0	0	0	0	0	0	0
24	0	0	0	0	0	0	0	0	0	0	0	0	0	0
25	0	0	0	0	0	0	0	0	0	0	0	0	0	0
26	0	0	0	0	0	0	0	0	0	0	0	0	0	0
27	0	0	0	0	0	0	0	0	0	0	0	0	0	0
28	0	0	0	0	0	0	0	0	0	0	0	0	0	0
29	0	0	0	0	0	0	0	0	0	0	0	0	0	0
30	0	0	0	0	0	0	0	0	0	0	0	0	0	0

DATE	CHANGE NO.	DATE	CHANGE NO.	INTERNATIONAL BUSINESS MACHINES CORP.
4-10-62	113220	01.7.62	TA 1970 K	NAME
				FIGURE 52
				% AAA BBB
				DIVIDE
				DESIGN
				TYPE
				DETAIL
				SCALE
				NONE
				CHECK
				DRAW
				VE
				3-28-62