

Appendix B. Alphabetical Index of Card Codes

Card Code	Description	Part No.	Symbol
CURRENT MODE			
AA--	Two-Way AND (no loads)	371207	+A
AAZU	Two-Way AND (out-of-phase load)	371206	+A
AAZV	Two-Way AND (in-phase load)	371205	+A
AAZW	Two-Way AND (both loads)	371204	+A
AB--	Two-Way OR (no loads)	371216	+O
ABZU	Two-Way OR (out-of-phase load)	371215	+O
ABZV	Two-Way OR (in-phase load)	371214	+O
ABZW	Two-Way OR (both loads)	371213	+O
ACYV	Four-Way AND-Block Extender	371227	E
ACYW	Two-Way AND-Block Extender	371226	E
ACYX	Three-Way AND (no loads)	371221	+A
ACYY	Three-Way AND (out-of-phase load)	371220	+A
ACYZ	Three-Way AND (in-phase load)	371219	+A
ACZA	Three-Way AND (both loads)	371218	+A
ACZF	Four-Way AND (no loads)	371225	+A
ACZG	Four-Way AND (out-of-phase load)	371224	+A
ACZH	Four-Way AND (in-phase load)	371223	+A
ACZJ	Four-Way AND (both loads)	371222	+A
ADYV	Four-Way OR-Block Extender	371237	E
ADYW	Two-Way AND-Block Extender	371236	E
ADYX	Three-Way OR (no loads)	371231	+O
ADYY	Three-Way OR (out-of-phase load)	371230	+O
ADYZ	Three-Way OR (in-phase load)	371229	+O
ADZA	Three-Way OR (both loads)	371228	+O
ADZF	Four-Way OR (no loads)	371235	+O
ADZG	Four-Way OR (out-of-phase load)	371234	+O
ADZH	Four-Way OR (in-phase load)	371233	+O
ADZJ	Four-Way OR (both loads)	371232	+O
AEWY	N Line Complemented Emitter Follower	371238	DE
AEWZ	P Line Complemented Emitter Follower	371239	DE
AF--	N Line Terminator	371242	DT
AG--	Line Driver Coupling Network	371240	R
AK--	N and P Block Coupling Networks	371241	R
AL--	P Line Line Terminator	371243	DT
AM--	N to P Converter (no loads)	371203	C
AMWX	N Line Driver	371208	DL
AMZX	N to P Converter (out-of-phase load)	371202	C
AMZY	N to P Converter (in-phase load)	371201	C
AMZZ	N to P Converter (both loads)	371200	C
AN--	P to N Converter (no loads)	371212	C
ANWX	P Line Driver	371217	DL
ANZX	P to N Converter (out-of-phase load)	371211	C
ANZY	P to N Converter (in-phase load)	371210	C
ANZZ	P to N Converter (both loads)	371209	C
AQ--	P to S Current Mode to Voltage Mode Converter	371031	C
CURRENT MODE			
AW--	3. 2-215 Microsecond Universal Single Shot	371039	SS
BGWA	W to N and W to P Integrators	371430	C
BGWB	W to N and W to P Integrators	371429	C
BGWC	W to N Integrators	371428	C
BGWD	W to P Integrators	371427	C
CTDL			
CG--	Two-Way-AND (no loads)	371263	-A
CGVV	Two-Way-AND (1 load)	371262	-A
CGVW	Two-Way-AND (2 loads)	371261	-A
CGWW	Two-Way-AND (all loads)	371251	-A
CH--	Two-Way+AND (no loads)	371266	+A
CHVV	Two-Way+AND (1 load)	371265	+A
CHVW	Two-Way+AND (2 loads)	371264	+A
CHWW	Two-Way+AND (all loads)	371252	+A
CJ--	Three-Way-AND (no loads)	371268	-A
CJVU	Three-Way-AND (1 load)	371267	-A
CJWV	Three-Way-AND (2 loads)	371253	-A
CJYC	Three-Way-AND (2 loads) (Ext. In)	371071	-A
CK--	Three-Way+AND (no loads)	371270	+A
CKVU	Three-Way+AND (1 load)	371269	+A
CKWV	Three-Way+AND (2 loads)	371254	+A
CKYC	Three-Way+AND (2 loads) (Ext. In)	371072	+A
CLVQ	Extender and Limiter Card	371255	E
CLVR	Extender and Limiter Card	371075	E

Card Code	Description	Part No.	Symbol
CTDL			
CLVS	Extender and Limiter Card	371074	E
CLVT	Extender and Limiter Card	371073	E
CM--	CM to CTDL Coupling Network	371256	R
CNWT	Emitter Follower NPN	371260	DE
CNWU	U to T Converter	371258	C
CPWT	Emitter Follower PNP	371259	DE
CPWU	T to U Converter	371257	C
CQ--	T to U Converter (no loads)	371273	C
CQYG	T to U Converter (1 load)	371278	C
CQZT	T to U Converter (2 loads)	371272	C
CQZV	T to U Converter (4 loads)	371271	C
CR--	U to T Converter (no loads)	371276	C
CRYG	U to T Converter (1 load)	371277	C
CRZT	U to T Converter (2 loads)	371275	C
CRZV	U to T Converter (4 loads)	371274	C
CS--	N Type Line Driver	371520	DL
CT--	P Type Line Driver	371521	DL
CU--	N Type Line Terminator	371518	DT
CV--	P Type Line Terminator	371519	DT
CW--	Trigger	371534	T
CY--	Power Inverter	371542	IP
DIFFUSED JUNCTION			
DAZU	Two-Way AND, Type A (out-of-phase load)	371281	+A
DAZW	Two-Way AND, Type A (both loads)	371280	+A
DAZX	N to P Converter, Type A (out-of-phase load)	371283	C
DAZZ	N to P Converter, Type A (both loads)	371282	C
DB--	N to P Converter, Type B (no loads)	371295	C
DBYD	Two-Way AND, Type B (Ckt 1, both loads) (Ckt 2, in-phase load)	371359	+A
DBZP	Plus Exclusive OR (no loads)	371291	+OE
DBZQ	Plus Exclusive OR (out-of-phase load)	371290	+OE
DBZR	Plus Exclusive OR (in-phase load)	371289	+OE
DBZS	Plus Exclusive OR (both loads)	371288	+OE
DBZT	Two-Way AND, Type B (no loads)	371287	+A
DBZU	Two-Way AND, Type B (out-of phase load)	371286	+A
DBZV	Two-Way AND, Type B (in-phase load)	371285	+A
DBZW	Two-Way AND, Type B (both loads)	371284	+A
DBZX	N to P Converter, Type B (out-of-phase load)	371294	C
DBZY	N to P Converter, Type B (in-phase load)	371293	C
DBZZ	N to P Converter, Type B (both loads)	371292	C
DCZU	Two-Way OR, Type A (out-of-phase load)	371297	+O
DCZW	Two-Way OR, Type A (both loads)	371296	+O
DCZX	P to N Converter, Type A (out-of-phase load)	371299	C
DCZZ	P to N Converter, Type A (both loads)	371298	C
DD--	P to N Converter, Type B (no loads)	371311	C
DDZP	Minus Exclusive OR (no loads)	371307	-OE
DDZQ	Minus Exclusive OR (out-of-phase load)	371306	-OE
DDZR	Minus Exclusive OR (in-phase load)	371305	-OE
DDZS	Minus Exclusive OR (both loads)	371304	-OE
DDZT	Two-Way OR, Type B (no loads)	371303	+O
DDZU	Two-Way OR, Type B (out-of-phase load)	371302	+O
DDZV	Two-Way OR, Type B (in-phase load)	371301	+O
DDZW	Two-Way OR, Type B (both loads)	371300	+O
DDZX	P to N Converter, Type B (out-of-phase load)	371310	C
DDZY	P to N Converter, Type B (in-phase load)	371309	C
DDZZ	P to N Converter, Type B (both loads)	371308	C
DEYR	N to P Terminator-Buffer-Converter (out-of-phase load)	371329	CBT
DEYS	N to P Terminator-Buffer-Converter (both loads)	371328	CBT
DEYT	N to P Buffer Converter (out-of-phase load)	371327	CB