

0729050

MANUAL CONTROLS SECTION 3

1401

31.03.31.2

TAG DATE

+U ACTIVATE MEMORY 31.02.41.2

-T START 31.01.11.2

+U START OR MANUAL ENTRY 37.41.12.2

+U TIME 090-000 31.12.62.2

-T MANUAL ENTRY 31.03.11.2

+U TIME 075-000 34.33.13.2

+U MODE SELECT 31.03.21.2

-T D CYCLE SET 37.41.12.2

+U ALTER 31.03.11.2

+U CHARACTER DISPLAY 37.30.11.2

+U NOT CHAR DISPLAY 37.30.11.2

+U PR SCAN END 31.02.31.2

+U TIME 075-105 31.12.91.2

+U STORAGE SCAN 37.30.12.2

+U STORAGE SCAN ERROR 31.09.11.2

+U NOT MANUAL ENTRY LAT 31.03.11.2

-T D CYCLE RST 37.41.12.2

+U NOT START INLK 31.01.11.2

+U NOT STORAGE PRINT OUT 37.30.11.2

-T ACT MEM NOT START OR ENTER 31.17.71.2  
-T ACT MEM NOT START OR ENTER 32.33.31.2

+U TIME 090-000 31.06.11.2

-T D CYCLE SET 32.36.11.2

+U CHARACTER DISPLAY 31.03.21.2

-T GATED D CYCLE 31.24.11.2

-T GATED D CYCLE 32.34.11.2

+U STORAGE SCAN 31.03.21.2

+U STORAGE SCAN 31.03.11.2

+U NOT D CYCLE LATCH 31.04.11.2

+U TIME 075-105 31.04.11.2

+U TIME 075-105 31.20.11.2

-T D CYCLE 31.02.41.2

-T D CYCLE 32.33.31.2

-T D CYCLE 37.41.12.2

+U NOT STORAGE PRINT OUT 31.25.11.2

+U NOT STORAGE PRINT OUT 31.24.11.2

- \*1-01B2A22F
- \*5-01B2F03C
- \*A-01B2F03K
- \*1A-01A7D26P
- \*1B-01B8RC03

- \*1-01B8RC35
- \*6-01B2F030
- \*B-01B2D03M
- \*E-01B2D026

- \*2-01B2F01P
- \*7-01B2F01R
- \*1A-01A3D24M
- \*1A-01A7F256

- \*3-01B2D04R
- \*8-01B2F03D
- \*C-01B2D020
- \*F-01B2D02R

- \*4-01B2F02P
- \*9-01B2B22A
- \*1A-01A7F250
- \*1A-01A7F25R

- \*1B-01B8RC02
- \*1B-01B8RC13
- \*D-01B2F02P
- \*6-01B2D02R

729058

NOTE: WHEN A SIGNAL IS PRECEDED BY AN ASTERISK, ITS EXPANSION INDICATES CABLE WIRING FOR REMOTE RECYCLE CONTROL INSTALLATION.

TAG DATE E.C.NO. A 12-15-61 113530 E 11-30-63 114182

TAG DATE E.C.NO. B 05-03-62 114141

TAG DATE E.C.NO. C 10-23-62 114166

TAG DATE E.C.NO. D 12-16-62 114176