

SENSE SWITCH E OFF - Machine prints error results. Examples of error print-out:

<u>D Modifier</u>	<u>B Field Characters</u>	<u>Result Should Be</u>	<u>Result Is</u>
1	1	Equal	ERROR
2	2	Equal	ERROR
1	24	Unequal	ERROR
1	8/-	Unequal	ERROR

NOTE: In the case of test for unequal characters the d modifier (1 in example 3) was compared with B Field Characters 4, 2, and blank in that order; in example 4 it was compared with -, /, and 8. The first error detected caused the error print-out.

SENSE SWITCH C ON - Machine prints correct results. Examples:

<u>D Modifier</u>	<u>B Field Characters</u>	<u>Result Should Be</u>	<u>Result Is</u>
1	1	Equal	Equal
2	2	Equal	Equal
1	24	Unequal	Unequal
1	8/-	Unequal	Unequal