

PROGRAM LISTING

FORMS SPACING BLOCK 20008

,008012,019,026030L0653681001,008012,00110011B361080AB421/340080 1 OF 2 20008 02
 ,037044N000,340344,348349,357,361368/333080 PROG. CHAIN. ROUTINE 2 OF 2 20008 03
 L057S4510012,049L072772/2772□/40/60□/80L/892702/2702413 CARD 1 OF 3 20008 04
 ,019026,033,040044,051051/340001 TITLE PRINT ROUTINE CARD 2 OF 3 20008 05
 ,S01S05,S12,S13S17,S18S25,S29S36,S37S41,S45/333080 CARD 3 OF 3 20008 06

LOAD	INST	ADDR	ADDR	OP	A	B	REMARKS	
396	377	B	389	S	611		USE WHEN TESTS ARE RUN FROM TAPE	07
404	385	B	588				''	08
408	389	N	000				''	09
412	393	M	360	392			''	10
419	400	/	332				CLEAR PRINT AREA	11
423	404	/					''	12
424	405	L	750	S	22		MODIFY TITLE PRINT TO SKIP HEADINGS	13
431	412	B	500	S	521		BR TO TITLE PRINT ROUTINE IF 1 IN S52	14
439	420	,	201				SET WORD MARK IN PRINT AREA	15
443	424	M	800	332			MOVE HYPHEN INTO 332	16
450	431	M	332	331			MOVE HYPHEN INTO ALL PRINT POSITIONS	17
457	438	L	820	250			LOAD PRINT-AUTO.-SPACE---	18
464	445	L	942	944			LOAD 1 INTO LINE COUNTER	19
471	452	C	944	946			COMPARE LINE COUNTER WITH CONSTANT 05	20
478	459	B	468	/			UNEQUAL BRANCH TO PRINT	21
483	464	B	485				EQUAL BRANCH TO CHANGE OPERATION COMMENT	22
487	468	2					PRINT OPERATION COMMENT	23
488	469	B	468	B			B ON TO SCOPE	24
493	474	A	942	944			ADD 1 TO LINE COUNTER	25
500	481	B	452				BRANCH TO LOOP	26
504	485	L	840	250			LOAD AFTER-PRINT-SPACE-1-	27
511	492	C	944	948			COMPARE LINE COUNTER WITH CONSTANT 09	28
518	499	B	508	/			UNEQUAL BRANCH TO FORMS CONTROL	29
523	504	B	527				EQUAL BRANCH TO CHANGE OPERATION COMMENT	30
527	508	F	/				FORMS CONTROL	31
529	510	2					PRINT OPERATION COMMENT	32
530	511	B	508	B			B ON TO SCOPE	33
535	516	A	942	944			ADD 1 TO LINE COUNTER	34
542	523	B	492				BRANCH TO LOOP	35
546	527	L	860	250			LOAD AFTER-PRINT-SPACE-2-	36
553	534	C	944	950			COMPARE LINE COUNTER WITH CONSTANT 13	37
560	541	B	550	/			UNEQUAL BRANCH TO FORMS CONTROL	38
565	546	B	569				EQUAL BRANCH TO CHANGE OPERATION COMMENT	39
569	550	F	S				FORMS CONTROL	40
571	552	2					PRINT OPERATION COMMENT	41
572	553	B	550	B			B ON TO SCOPE	42
577	558	A	942	944			ADD 1 TO LINE COUNTER	43
584	565	B	534				BRANCH TO LOOP	44
588	569	L	880	250			LOAD AFTER-PRINT-SPACE-3-	45
595	576	C	944	952			COMPARE LINE COUNTER WITH CONSTANT 17	46
602	583	B	592	/			UNEQUAL BRANCH TO FORMS CONTROL	47

2000B-5

DATE								
ENG. CHG. NO.								