

Checking Procedure

SENSE SWITCH E ON - Machine stops for errors.

1. Remove the last card in the stacker.
2. Visually check columns 41-48 in the card with Locations 241-248; then check Locations 241-248 with Locations 261-268.
3. Check B ≠ A logic light. Should be OUT if STARS SHOULD BE and STARS ARE are the same; should be ON if not.

SENSE SWITCH E OFF - Machine prints error results. Examples:

<u>Indexed Instruc.</u>	<u>Index Registers</u>	<u>STARS Should Be</u>	<u>STARS Are</u>	<u>Process On</u>	
N5W7890	111 *** ***	678 890	6X8 890	1248-&	ERROR
N/T5SD6	ALA *** D5F	246 702	B46 X02	1248-&	ERROR
N//1BK2	J35 R8G ***	B46 K09	K46 B09	48-&	ERROR

SENSE SWITCH C ON - Machine prints correct results. Examples:

N5W7890	111 *** ***	678 890	678 890	1248-&	
N/T5SD6	ALA *** D5F	246 702	246 702	1248-&	
N//1BK2	J35 R8G ***	B46 K09	B46 K09	48-&	

Procedure for Running Indexing and Store STARS Test from Tape

1. Manually enter "1" in Location S57.
 2. Set Sense Switch "F" to the OFF position.
- NOTE: This will allow the Indexing and Store STARS Test to be executed with all other tests that may be chained.

Procedure for Running ONLY Indexing and Store STARS Test from Tape

1. Manually enter Block No. 3100 in Locations S73-S76 and "1" in S57.
 2. Set Sense Switch "F" to the ON position.
- NOTE: This will allow only the Indexing and Store STARS Test to be executed, by-passing all the others.