

PROGRAM LISTING

19 MODIFY ADDRESS BLOCK 3700A

,008012,019,026030L0653661001,008012,00110011B361080AB421/340080 1 OF 2 3700A 02
 ,037044N000,340344,348349,357,361368/333080 PROG. CHAIN. ROUTINE 2 OF 2 3700A 03
 L057S4510012,049L0772772/2772□/40/60□/80L/892702/2702413 CARD 1 OF 3 3700A 04
 ,019026,033,040044,051051/340001 TITLE PRINT ROUTINE CARD 2 OF 3 3700A 05
 ,S01S05,S12,S13S17,S18S25,S29S36,S37S41,S45/333080 CARD 3 OF 3 3700A 06

LOAD ADDR	INST ADDR	OP	A	B	REMARKS	
396	377	B	389	S641	USE WHEN TESTS ARE RUN FROM TAPE	07
404	385	B	S88		..	08
408	389	N	000		..	09
412	393	M	360	392	..	10
419	400	/	332		START TEST	11
423	404	/				12
424	405	B	S00	S521	BR TO TITLE PRINT ROUTINE IF 1 IN S52	13
432	413	/	080		CLEAR READ AREA	14
436	417	B	348		BRANCH TO PROGRAM CHAINING ROUTINE	15
440	421	,	001	078	LOAD PRINT AREA	16
447	428	L	080	299	..	17
454	435	L	072	272	..	18
461	442	,	221	241	..	19
468	449	L	224	264	LOAD B FIELD	20
475	455	,	203	264	..	21
482	463	#	204	264	MODIFY ADDRESS	22
489	470	B	449	B	B ON TO SCOPE	23
494	475	□	264		TEST FOR ERROR	24
498	479	C	264	244	..	25
505	486	B	900	/	BRANCH TO ERROR PRINT ROUTINE IF UNEQ	26
510	491	B	950	C	C ON TO CORRECT PRINT ROUTINE	27
515	496	B	958		BRANCH TO SENSE D	28
919	900	L	/14	285	BEGIN ERROR PRINT ROUTINE	29
926	907	B	916	L	L ON TO ERROR STOP	30
931	912	2	958		ERROR PRINT	31
935	916	.	958		ERROR STOP	32
939	920				WORD MARK	33
969	950	L	/19	285	CORRECT PRINT ROUTINE	34
976	957	2			..	35
977	958	B	421	D	D ON TO REPEAT	36
982	963	B	417		BRANCH TO READ NEXT RECORD	37
729	710	E	RRO	R	CONSTANTS	38
734	715				..	39
739	720	A	FI	ELD	..	40
759	740	B	FI	ELD	..	41
779	760	R	ESU	LT SHOULD BE	..	42
799	780	R	ESU	LT IS	..	43
,019027,031,039042B031T98#3400L0463520W048588					MODIFY ADDRESS	3700A 44
					DETAIL CARDS	
000				000		3700A 45

3700A-4

DATE							
ENG. CHG. NO.							