FORMS SPACING BLOCK 2000B

```
,008012,019,026030L0653681001,008012,00110011B361080AB421/340080 1 OF 2 2000B 02
,037044N000,340344,348349,357,361368/333080 PROG. CHAIN. ROUTINE 2 OF 2 2000B 03
L057S4510012,049L0772772/2772¤/40/60¤/80L/892702/2702413    CARD 1 OF 3 2000B 04
,019026,033,040044,051051/340001       TITLE PRINT ROUTINE  CARD 2 OF 3 2000B 05
,S01S05,S12,S13S17,S18S25,S29S36,S37S41,S45/333080           CARD 3 OF 3 2000B 06
```

LOAD ADDR	INST ADDR	OP	A	B	REMARKS	
396	377	B	389	S611	USE WHEN TESTS ARE RUN FROM TAPE	07
404	385	B	S88		,,	08
408	389	N	000		,,	09
412	393	M	360	392	,,	10
419	400	/	332		CLEAR PRINT AREA	11
423	404	/			,,	12
424	405	L	750	S22	MODIFY TITLE PRINT TO SKIP HEADINGS	13
431	412	B	S00	S521	BR TO TITLE PRINT ROUTINE IF 1 IN S52	14
439	420	,	201		SET WORD MARK IN PRINT AREA	15
443	424	M	800	332	MOVE HYPHEN INTO 332	16
450	431	M	332	331	MOVE HYPHEN INTO ALL PRINT POSITIONS	17
457	438	L	820	250	LOAD PRINT-AUTO.-SPACE---	18
464	445	L	942	944	LOAD 1 INTO LINE COUNTER	19
471	452	C	944	946	COMPARE LINE COUNTER WITH CONSTANT 05	20
478	459	B	468	/	UNEQUAL BRANCH TO PRINT	21
483	464	B	485		EQUAL BRANCH TO CHANGE OPERATION COMMENT	22
487	468	2			PRINT OPERATION COMMENT	23
468	469	B	468	8	B ON TO SCOPE	24
493	474	A	942	944	ADD 1 TO LINE COUNTER	25
500	481	B	452		BRANCH TO LOOP	26
504	485	L	840	250	LOAD AFTER-PRINT-SPACE-1-	27
511	492	C	944	948	COMPARE LINE COUNTER WITH CONSTANT 09	28
518	499	B	508	/	UNEQUAL BRANCH TO FORMS CONTROL	29
523	504	B	527		EQUAL BRANCH TO CHANGE OPERATION COMMENT	30
527	508	F	/		FORMS CONTROL	31
529	510	2			PRINT OPERATION COMMENT	32
530	511	B	508	8	B ON TO SCOPE	33
535	516	A	942	944	ADD 1 TO LINE COUNTER	34
542	523	B	492		BRANCH TO LOOP	35
546	527	L	860	250	LOAD AFTER-PRINT-SPACE-2-	36
553	534	C	944	950	COMPARE LINE COUNTER WITH CONSTANT 13	37
560	541	B	550	/	UNEQUAL BRANCH TO FORMS CONTROL	38
565	546	B	569		EQUAL BRANCH TO CHANGE OPERATION COMMENT	39
569	550	F	S		FORMS CONTROL	40
571	552	2			PRINT OPERATION COMMENT	41
572	553	B	550	8	B ON TO SCOPE	42
577	558	A	942	944	ADD 1 TO LINE COUNTER	43
584	565	B	534		BRANCH TO LOOP	44
588	569	L	880	250	LOAD AFTER-PRINT-SPACE-3-	45
595	576	C	944	952	COMPARE LINE COUNTER WITH CONSTANT 17	46
602	583	B	592	/	UNEQUAL BRANCH TO FORMS CONTROL	47

DATE								
ENG. CHG. NO.								