**Four Sense Switches may be brought into play as follows:**

**Sense Switch B ON - permits scoping of Compare and Br High operations as often as desired.**
**Sense Switch D ON - permits execution of the Error Print Routines as often as desired.**
**Sense Switch E OFF - prints for error results.**
**ON - stops for error results.**
**Sense Switch G ON - repeats the program for the entire test as often as desired.**

The following characters and blanks are stored in ascending sequence by the loading routine in Locations 701-830, except the word marks in all odd-numbered positions, the Word Separator Character in Location 733, and the a-bit in Location 739 which are program generated:

| | 12 12 12 | 11 11 11 | 0 0 0 | | | |
|---|---|---|---|---|---|---|
| | 5 6 7 | 5 6 7 | 5 6 7 | 5 6 7 12 | | |
| | . ¤ 8 8 8 ¢ $ * 8 8 8 - / , % 8 8 8 a # @ 8 8 8 o A B C D E F | | | | | |
| (777777 | | | 77 | 77 | | 77 |
| Loc. (000000 | | | 33 | 34 | | 66 |
| (123456 | | | 34 | 90 | | 34 |

| | 0 | | | | |