3. Press Tape Load Button.

4. When Program stops loading, make desired switch settings and press Start. (If the switches are not installed on your machine, place a WM "N" in the (d) modifier position of the inst. where the branch is desired).

5a. If Inquiry Typeout occurs (Switch G on), press Inquiry button and then Start button. Now key in Diagnostic ID number desired.

Example: F 7005 Note: Do Not Key in Just 7005. System will not work.

5b. Release by pressing Respond/Typeout Key.

6a. Program will then search tape for Diagnostic with serial ID number.

6b. If an improper ID is given, the 1407 will type "NO SUCH ID ON TAPE."

7. Program will load automatically and start executing instructions. If switch D is on, program will continually loop. If D is off, program will operate through "Tape Chaining Routine" and execute remaining diagnostics on tape.

8. If switch C is on and G is off, the tape executive program will automatically branch to 001 and the first diagnostic will be executed.

9. The remaining diagnostics will be executed if switch D is off (see #7).

10. After the last diagnostic is executed, the diagnostic tape will automatically rewind and Halt.

B. Without 1407 or Switch G OFF

1. Same as with 1407 (see above, Section II, A)

2. Same as with 1407

3. Same as with 1407

4. Same as with 1407