

DIAGNOSTIC FUNCTION TEST

SET WORDMARK CARD

THE SET WM CARD HAS THIS FORMAT.

COLUMNS

0	1	2	3	4	5	6	7	8
1234567890	1234567890	1234567890	1234567890	1234567890	1234567890	1234567890	1234567890	1234567890
,008015,022029,033033N			1001	SET WORDMARK CARD				XXXX 02

THE SET WM CARD IS NECESSARY ONLY WHEN DECKS ARE CHAINED. AFTER THE TITLE CARD IS READ, THE READ AREA IS CLEARED, A WM IS SET IN COLUMN 1, A CARD IS FED, AND THE PROGRAM BRANCHES TO COLUMN ONE. ALL THIS IS THE RESULT OF THE CHAINING ROUTINE. CONSEQUENTLY, WORD MARKS MUST AGAIN BE SET UP FOR THE PACKED CARDS. THE SET WORDMARK CARD DOES THIS.

CLEAR WORDMARK CARD

THE CLEAR WM CARD HAS THIS FORMAT.

COLUMNS

0	1	2	3	4	5	6	7	8
1234567890	1234567890	1234567890	1234567890	1234567890	1234567890	1234567890	1234567890	1234567890
/333080N				CLEAR WORDMARK CARD				XXXX 36

THIS CARD CAUSES THE READ-IN AREA TO BE CLEARED AND CAUSES A BRANCH TO THE CHAINING ROUTINE. THE CHAINING ROUTINE SETS UP WORD MARKS FOR THE TRAILER CARD AND CAUSES THE TRAILER CARD TO FEED.

DATE	5/1/62							
ENG. CHG. NO.	113459							