

PROGRAM LISTING

TEST CHARACTER & BRANCH BLOCK 0050A

,008012,019,026030L0653681001,008012,00110011B361080AB421/340080 1 OF 2 0050A 02
 ,037044N000,340344,348349,357,361368/333080 PROG. CHAIN. ROUTINE 2 OF 2 0050A 03
 L057S4510012,049L0772772/2772□/40/60□/80L/892702/2702413 CARD 1 OF 3 0050A 04
 ,019026,033,040044,051051/340001 TITLE PRINT ROUTINE CARD 2 OF 3 0050A 05
 ,S01S05,S12,S13S17,S18S25,S29S36,S37S41,S45/333080 CARD 3 OF 3 0050A 06

LOAD ADDR	INST ADDR	OP	A	B	REMARKS	
396	377	B	389		USE WHEN TESTS ARE RUN FROM TAPE	07
404	385	B	S88		''	08
408	389	N	000		''	09
412	393	M	360	392	''	10
419	400	/	332		START TEST	11
423	404	/				12
424	405	B	S00	S521	BR TO TITLE PRINT ROUTINE IF 1 IN S52	13
432	413	/	080		CLEAR READ AREA	14
436	417	B	348		BRANCH TO PROGRAM CHAINING ROUTINE	15
440	421	,	001	078	LOAD PRINT AREA	16
447	428	L	080	299	''	17
454	435	L	072	272	''	18
461	442	,	202	241	''	19
468	449	M	250	456	MOVE B OR N OP INTO 456	20
475	456		486		B OP FOR EQUAL CHAR-N OP FOR UNEQ CHAR	21
479	460	M	202	474	MOVE D MODIFIER TO TEST CHARAC OP	22
486	467	B	895	224X	TEST UNEQUAL CHARACTERS	23
494	475	B			''	24
495	476	B			''	25
496	477	B	467	B	B ON TO SCOPE	26
501	482	B	515		BRANCH TO LOAD RESULT COMMENT	27
505	486	M	202	500	MOVE D MODIFIER TO TEST CHARAC OP	28
512	493	B	510	222X	TEST EQUAL CHARACTERS	29
520	501	B	493	B	B ON TO SCOPE	30
525	506	B	900		BRANCH TO ERROR PRINT ROUTINE	31
529	510	B	493	B	B ON TO SCOPE	32
534	515	L	247	267	LOAD RESULT COMMENT	33
541	522	B	950	C	C ON TO CORRECT PRINT ROUTINE	34
546	527	B	958		BRANCH TO SENSE D	35
914	895	B	467	B	B ON TO SCOPE	36
919	900	L	/14	285	BEGIN ERROR PRINT ROUTINE	37
926	907	B	916	E	E ON TO ERROR STOP	38
931	912	2	958		ERROR PRINT	39
935	916	.	958		ERROR STOP	40
939	920				WORD MARK	41
969	950	L	/19	285	CORRECT PRINT ROUTINE	42
976	957	2			''	43
977	958	B	421	D	D ON TO REPEAT	44
982	963	/	280		CLEAR	45
986	967	/	080		''	46
990	971	B	417		BRANCH TO READ NEXT RECORD	47

0050A-6

DATE							
ENG. CHG. NO.							