

PROGRAM LISTING

COMPARE & BR UNEQUAL BLOCK 0100A

.008012,019,026030L0653681001,008012,CC110011B361080AB421/340080 1 OF 2 0100A 02
 ,037044N000,340344,348349,357,361368/333080 PROG. CHAIN. ROUTINE 2 OF 2 0100A 03
 ,S7S4510012,049L0772772/27720/40/600/80L/892702/2702413 CARD 1 OF 3 0100A 04
 ,019026,033,040044,051051/340001 TITLE PRINT ROUTINE CARD 2 OF 3 0100A 05
 ,001905,S12,S13S17,S18S25,S29S36,S37S41,S45/333080 CARD 3 OF 3 0100A 06

LOC	INST	ADDR	ADDR	OP	A	B	REMARKS	
396	377	B	389				USE WHEN TESTS ARE RUN FROM TAPE	07
404	385	B	S88				..	08
408	389	N	000				..	09
412	393	M	360	392			..	10
419	400	/	332				START TEST	11
423	404	/						12
424	405	B	S00	S521			BR TO TITLE PRINT ROUTINE IF 1 IN S52	13
432	413	/	080				CLEAR READ AREA	14
436	417	B	348				BRANCH TO PROGRAM CHAINING ROUTINE	15
440	421	.	002	078			LOAD PRINT AREA	16
447	428	L	080	299			..	17
454	435	L	072	272			..	18
461	442	B	458	046L			BR TO MAKE B FIELD LARGER IF L IN 046	19
469	450	.	222				SET B FLD WM IF NO L IN 046	20
473	454	B	462				BRANCH TO COMPARE	21
477	458	.	221				SET B FLD WM IF L IN 046	22
481	462	C	203	223			COMPARE & BRANCH UNEQUAL	23
488	469	B	491	/			..	24
493	474	E	462	B			B CN TO SCOPE	25
498	479	B	508	041			NO ERROR IF BLANK IN 041	26
506	487	B	900				BRANCH TO ERROR PRINT ROUTINE	27
510	491	B	462	B			B CN TO SCOPE	28
515	496	B	508	041U			NO ERROR IF U IN 041	29
523	504	B	900				BRANCH TO ERROR PRINT ROUTINE	30
527	508	.	241				LOAD RESULT COMMENT	31
531	512	L	260	280			..	32
538	519	B	950	C			C CN TO CORRECT PRINT ROUTINE	33
543	524	B	958				BRANCH TO SENSE D	34
549	900	L	/14	285			BEGIN ERROR PRINT ROUTINE	35
526	907	B	916	E			E CN TO ERROR STOP	36
531	912	2	958				ERROR PRINT	37
535	916	.	958				ERROR STCP	38
539	920						WORD MARK	39
569	950	L	/19	285			CORRECT PRINT ROUTINE	40
576	957	2					..	41
577	958	B	421	D			D CN TO REPEAT	42
582	963	B	417				BRANCH TO READ NEXT RECORD	43
729	/10	E	ARO	R			CONSTANTS	44
734	/15						..	45
739	/20	A	FI	ELD			..	46

0100A-4

DATE							
ENG. CHG. NO.							