

PROGRAM LISTING

LOAD COMPARE BLOCK 0110A

,008012,019,026030L0653681001,008012,00110011,361080A8421/340080 1 OF 2 0110A 02
 ,037044N000,340344,348349,357,361368/333080 PROG. CHAIN. ROUTINE 2 OF 2 0110A 03
 LC57S4510012,049LC772772/2772#40/60#36L/892702/2702413 CARD 1 OF 3 0110A 04
 ,019026,033,040044,051051/340001 TITLE PRINT ROUTINE CARD 2 OF 3 0110A 05
 ,S01505,S12,S13S17,S18S25,S29S36,S37S41,S45/333080 CARD 3 OF 3 0110A 06

LOAD	INST	ADDR	ADDR	CP	A	B	REMARKS	
396	377	B	389				USE WHEN TESTS ARE RUN FROM TAPE	07
404	385	B	S08				''	08
408	389	N	000				''	09
412	393	M	360	392			''	10
419	400	/	332				START TEST	11
423	404	/						12
424	405	B	S00	S521			BR TO TITLE PRINT ROUTINE IF 1 IN S02	13
432	413	/	080				CLEAR READ AREA	14
436	417	B	348				BRANCH TO PROGRAM CHAINING ROUTINE	15
440	421	,	001	078			LOAD PRINT AREA	16
447	428	L	080	299			''	17
454	435	L	072	272			''	18
461	442	,	210	241			''	19
468	449	L	210	270			LOAD CP WITH CHAINING	20
475	456	L					''	21
476	457	B	449	B			B ON TO SCOPE	22
481	462	#	270				TEST FOR ERROR	23
485	466	C	270	250			''	24
492	473	B	900	/			BRANCH TO ERROR PRINT ROUTINE IF UNEQ	25
497	478	B	950	C			C ON TO CORRECT PRINT ROUTINE	26
502	483	B	958				BRANCH TO SENSE D	27
919	900	L	/14	285			BEGIN ERROR PRINT ROUTINE	28
926	907	B	916	E			E ON TO ERROR STOP	29
931	912	2	958				ERROR PRINT	30
935	916	.	958				ERROR STOP	31
939	920						WORD MARK	32
969	950	L	/19	285			CORRECT PRINT ROUTINE	33
976	957	2					''	34
977	958	B	421	D			D ON TO REPEAT	35
982	963	B	417				BRANCH TO READ NEXT RECORD	36
/29	/10	E	RRO	R			CONSTANTS	37
/34	/15						''	38
/39	/20	A	FI	ELD			''	39
/59	/40	B	FI	ELD			''	40
/79	/60	R	ESU	LT SHOULD BE			''	41
/99	/80	R	ESU	LT IS			''	42
,019027,031,038042B031T98#8400L046352BW04BS88							LOAD COMPARE	0110A 43
1111111111							DETAIL CARDS	0110A 44
2222222222								0110A 45
4444444444								0110A 4

0110A-4

DATE							
ENG. CHG. NO.							