

PROGRAM LISTING

BRANCH EQUAL BLOCK 3320A

,008012,019,026030L06536810C1,008012,001100118361080AB421/340080 1 CF 2 3320A 02
 ,037044N000,340344,348349,357,361368/333080 PROG. CHAIN. ROUTINE 2 OF 2 3320A 03
 L057S4510012,049L0772772/2772□/40/60□/80L/892702/2702413 CARD 1 OF 3 3320A 04
 ,019026,033,040044,051051/340001 TITLE PRINT ROUTINE CARD 2 OF 3 3320A 05
 ,S01S05,S12,S13S17,S18S25,S29S36,S37S41,S45/333080 CARD 3 OF 3 3320A 06

LOAD	INST	ACDR	ACDR	CP	A	B	REMARKS	
396	377	B	389	S	591		USE WHEN TESTS ARE RUN FROM TAPE	07
404	385	B	S88				..	08
408	389	N	000				..	09
412	393	M	360	392			..	10
419	400	/	332				START TEST	11
423	404	/						12
424	405	B	S00	S	521		BR TO TITLE PRINT ROUTINE IF 1 IN S52	13
432	413	/	C8C				CLEAR READ AREA	14
436	417	B	348				BRANCH TO PROGRAM CHAINING ROUTINE	15
440	421	,	CC1	078			LOAD PRINT AREA	16
447	428	L	080	299			..	17
454	435	L	072	272			..	18
461	442	,	222				..	19
465	446	C	203	223			COMPARE	20
472	453	B	475	S			BRANCH EQUAL	21
477	458	B	446	B			B ON TO SCOPE	22
482	463	B	492	041U			NO ERROR IF U IN 041	23
490	471	B	900				BRANCH TO ERROR PRINT ROUTINE	24
494	475	B	446	B			B ON TO SCOPE	25
499	480	B	492	041E			NO ERROR IF E IN 041	26
507	488	B	889				BRANCH TO ERROR PRINT ROUTINE	27
511	492	,	241				LOAD -RESULT IS- COMMENT	28
515	496	L	250	270			..	29
522	503	B	950	C			C ON TO CORRECT PRINT ROUTINE	30
527	508	B	958				BRANCH TO SENSE D	31
908	889	L	889	270			LOAD -RESULT IS- COMMENT	32
915	896	B	910				..	33
919	900	B	971	U			ERROR PRINT ROUTINE	34
924	905	B	982	T			..	35
929	910	L	714	285			..	36
936	917	B	926	E			E ON TO ERROR STOP	37
941	922	2	958				ERROR PRINT	38
945	926	.					ERROR STOP	39
946	927	B	958				BRANCH TO SENSE C	40
969	950	L	719	285			CORRECT PRINT ROUTINE	41
976	957	2					..	42
977	958	B	421	D			D ON TO REPEAT SAME COMPARE	43
982	963	/	280				CLEAR ANY GM-WM FROM PROGRAM	44
986	967	B	417				BRANCH TO READ NEXT RECCRD	45
990	971	L	999	270			LOAD -RESULT IS- COMMENT	46
997	978	B	910				..	47

3320A-5

DATE							
ENG CHG. NO.							