

CUSTOMER ENGINEERING TESTS
FOR THE 1401 DATA PROCESSING SYSTEM

Sheet 1 of 5
E.C. 110378
Part No. 451441

Block No. 3220A

BRANCH DIVIDE OVERFLOW

Purpose of Test

To test the Branch Overflow circuitry by dividing one factor by another and testing for an overflow condition. Errors are detected by checking the overflow condition with a blank character and no overflow with the letter "N". For errors the machine either stops to permit console checking or prints the results depending upon the setting of Sense Switch E.

A Branch Divide Overflow occurs when the divisor is zero or when the dividend is improperly addressed and the result of the first divide operation is greater than 9.

Units Required

1401 Processing Unit
1402 Card Reader or 729 Tape Drive (see procedure on page 2)
1403 Printer (optional)

Operations Used

Code

Clear	(/)
Set Word Marks	(,)
Load	(L)
Reset Add	(δ)
Branch Overflow	(B---Z)
Divide	(÷)
Test Character and Branch	(B-----)
Test Character and Branch	(B-----N)
Branch	(B)
Print	(2)
Stop (error)	(.)

Method of Test

The complete test block consists of the following cards:

1. Title Card (0A)
2. Two Program Chaining Routine Cards (02-03)
3. Three Title and Headings Print Routine Cards (04-06)
4. Four special program cards to set up instructions that are effective only when tests are run from tape (07-10)
5. Program Instruction Cards (11-47)
6. Detail Cards (48-51)

Four Sense Switches may be brought into play as follows:

Sense Switch B ON - permits scoping of the Branch Divide Overflow operations as often as desired.
Sense Switch C OFF - no printing for correct results.
ON - prints for correct results.
Sense Switch D ON - repeats the program for an individual card as often as desired.
Sense Switch E OFF - prints for error results.
ON - stops for error results.