

PROGRAM

CLEAR STORAGE 1 .008015,022026,030034,041,045,053,0570731026
CLEAR STORAGE 2 L072110,110106,1051176101/199,027A0740280027800102708026/0991,001/00111710
BOOTSTRAP CARD .008015,022029,056063/056029

PG LIN	CT	LABEL	OP	A OPERAND	B OPERAND	D	LOC	INSTRUCTION COMMENTS	F7100
A 001			CTL	33					
A 002			ORG	0400					
A 003									
A 004									
A 005									
A 006	7		SW	0001			0400	* 001 076	SET WORD MARKS
A 007	8		MCW	0001			0407	M 001 001 R	READ TAPE REC
A 008	1		H				0415	B 428	HALT FOR CTRLS
A 009	4		B	SAVE			0416	M 001 001 R	BR TO SAVE ID
A 010	8	START	MCW	0001			0420	M 001 001 R	READ TAPE REC
A 020	7	SAVE	MCW	0080			0428	M 080 674	SAVE ID
A 030	5		B	P11010			0435	R 502 C	BR SW G IS ON
A 040	5		B	0001			0440	R 001 C	BR SW C IS ON
A 050	7	P10050	C	0080			0445	C 080 574	COMP ID TO ID
A 060	5		B	P10110			+52	B 485 /	BR NOT EQUAL
A 070	8	P10070	MCW	0001			0457	M 001 001 R	READ TAPE REC
A 073	7		MCW	P13070E 3			0465	M 767 669	MOVE RETRN ADDR
A 074	5		B	P13010			0472	B 661 L	BR TAPE ERROR
A 080	4		B	P10050			0477	B 445	BR TO COMP ID
A 090	4	P10090	H	P10090			0481	B 481	ERROR HALT & BR
A 110	1	P10110	H				0485	C 080 680	HALT
A 120	7		C	0080			0486	C 080 680	COMP ID TO ID
A 130	5		B	SAVE			0493	B 428 /	BR NOT EQUAL
A 140	4	P10140	B	P10070			0498	B 457	BR TO COMPARE
A1 001									
A1 002									
A1 003									
A1 010	8	P11010	MCW	0001			0502	M 001 001 R	WR INQUIRY INFO
A1 020	8		MCW	0001			0510	M 001 001 R	CARR RETURN
A1 030	8		MCW	0001			0518	M 001 001 R	WR DIAG INFO
A1 040	8		MCW	0001			0526	M 001 001 R	CARR RETURN
A1 050	1		H				0534	B 444 Q	HALT FOR CTRLS
A1 060	5		B	P11110			0535	B 544 Q	BR INQUIRY
A1 070	4		B	P11010			0540	R 502	BR & WR INST

TAPE EXECUTIVE PROGRAM
DIAGNOSTIC TESTS

WR INST ON 1407 ROUTINE